



Arduino Uno Rev3

RESERVED
IOREF
RESET
3.3v
5.0v
GND
GND
VIN

A00 = D14
A01 = D15
A02 = D16
A03 = D17
SDA/A04 = D18
SCL/A05 = D19

PC0 - A0
PC1 - A1
PC2 - A2
PC3 - A3
PC4 - A4
PC5 - A5

SCL - PC5
SDA - PC4
AREF
GND
13 - PB5
12 - PB4
11 - PB3
10 - PB2
9 - PB1
8 - PB0
7 - PD7
6 - PD6
5 - PD5
4 - PD4
3 - PD3
2 - PD2
1 - PD1
0 - PD0